

Artemis 600/900 UL ■ astro


7239/7240

Sparta 600/900 UL

7241/7242

Axios 600/900 UL

7243/7244



Junction Box Installation
see page 3



Stub Out Installation
see page 6

EN

Please read the instructions carefully

F

Lire attentivement les instructions avant
de commencer le montage

EN

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR

F


CE PRODUIT DOIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAÎT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS CONSULTER UN ÉLECTRICIEN QUALIFIÉ POUR VOUS ASSURER QUE LES CONDUCTEURS DE LA DÉRIVATION SONT ADÉQUATS

Unsuitable for dimming.
Ne convient pour gradateur.
Nicht zum Dimmen geeignet.
No es apto para *dimming* (control de intensidad luminosa).


JUNCTION BOX INSTALLATION

OCTAGON JUNCTION BOX


1




2



3




4




USE FIXINGS SUITABLE
FOR THE WALL TYPE


5



6




7




STUB OUT INSTALLATION


1




2



3



4



5

